

Prescott Area Wood Turners

Club Demonstration : Salt pigs

Demonstrators: Bill McDonald/Don Milburn

Date: July 14, 2018

Project steps:

Select suitable wood. Calculate circle size and grain orientation.

Look for wood that will demonstrate the chatoyance effect.

Cut circle blanks to size.

Mark center point for screw chuck.

Attach screw chuck. Turn tenon on the top piece, Mortise on the bottom.

Locate bearing and magnet positions.

Cut bearing and pin to size.

Insert & glue magnet.

Insert pin but **DO NOT glue pin at this time.**

Put on lathe and turn edges to true.

Embellish outside at this time.

Attach to lathe and turn inside centers.

Sand and finish.

Install pin and glue.